



Kit 1220

DAIHATSU YRV, 5-dr Estate, 00-



480R
754



480



750



- 2 x2
- 2 x2
- 2 x2
- 4 x4
- 2 x2
- 2 x2
- 2 x2
- 2 x2
- 2 x2
- 4 x4
- 4 x4



Kit



3





754




750



1



2





DAIHATSU YRV, 5-dr Estate, 00-


X

28

1



2



DAIHATSU YRV, 5-dr Estate, 00-

Y

26




480R




480

1



2



DAIHATSU YRV, 5-dr Estate, 00-


X inch

X mm


36 5/8"

931 mm

1



2



DAIHATSU YRV, 5-dr Estate, 00-

Y inch







Y mm

35 7/8"

911 mm

4




DAIHATSU YRV, 5-dr Estate, 00-



5



	X mm	Y mm	X inch	Y inch
DAIHATSU YRV, 5-dr Estate, 00-	400 mm	700 mm	15 3/4"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielieciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagažníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันโนแบบสลับ







6



480R/754



480





THULE
SWEDEN
**ONE
KEY
SYSTEM**



- 544** (x4)
 - 596** (x6)
 - 588** (x8)
 - 510** (x10)
 - 510** (x10)
 - 452** (x12)
- NA
EUR
ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com